

User Manual – Theft Tracker **Hivemind**

Web: hivemind.co.nz

Phone: +64 3 741 1204

Aus: (02) 8188-2768

email: info@hivemind.co.nz

PO Box 2582

Christchurch 8140

New Zealand

System components:

- **Satellite theft tracker model 2** (see fig.1).
- Plastic mounting bracket
- 4 AAA lithium batteries (inside tracker)

Getting Started

1. Before installing in the field, test your tracker at home to make sure location data gets to the website.

2. Tracker mounting:

- Locate the tracker underneath a **plastic hive lid** using the mounting bracket (fig.1).

Do not mount under a metal lid as this will block the communication signals.

- Observe the message **“This side towards sky”**. Even if mounted under a hive lid, it must still face the sky. One way is to stick the mount bracket underneath the hive lid using double-sided tape. The tracker can be screwed into the mount bracket either way up, so ensure the logo faces the sky.

- If a **metal hive strap** is used, ensure that it does not cover the tracker.

3. **Turn on tracker:** Slide the black switch into the ON position as marked on the tracker. The device will now report location every 2 hours after movement.

Note: it will not work reliably indoors as it needs a view of the sky.

4. **Login:** Now browse to hivemind.co.nz/login and log in (first time you will need to create a password). Click on “Location history” to see the location of your hive tracker. If your tracker is new you may need to click a large “Activate” button: this will activate it within one day.



Fig. 1. Satellite tracker screwed onto mounting bracket



Fig. 2. Power button

Maintenance

Tracker batteries: Remove the battery compartment cover (4 screws) and install four AAA **lithium** batteries as shown here. Fully tighten screws to maintain waterproof seal. Only lithium batteries are suitable: other batteries will not operate reliably.

Specifications – Tracker

Dimensions: 68 x 51 x 24 mm

Weather proofing: IP67: waterproof up to a depth of 1m for 30 minutes

Operating temperature: -33 to 60 °C

Battery life: up to 1 a year depending on frequency of movement; replaceable with 4 x AAA 1.5V **Lithium**.

Location: Location (via satellite) accurate to within 10m radius

Report frequency: every 2 hours where sky is visible.

Regulatory Compliance

The satellite transmitter complies assuming a minimum operating distance of 20cm:

- CE (Europe Aus/NZ): ETSI EN 301 441 V1.1.1, ETSI EN301 489-1 V1.8.1(2008-04), ETSI EN 301 489-20 V1.2.1(2002-11)
- US FCC CFR47 parts 2, 15, and 25, UL913 intrinsically safe for Class I Division 1 Groups A-D
- Canada ICES-003
- EN60950-1:2006 Part 1; 1.7.13 notice: “Caution! Risk of explosion if battery is replaced by an incorrect type. Dispose of used batteries according to their instructions.”

FCC Notice: This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Device contains SM220 FCC ID: U90-SM220



Warranty

1. Purchased product warranty is 12 months from the date of purchase, day / mth / year as follows. Repair or replacement will be made to any faulty product returned to the purchasing location within that time. Hivemind will bear the cost of repair unless the product has been mistreated or operated outside specification. Hivemind will pay transit costs for only the transit of the product between the purchasing location and the repair facility.
2. Leased products have a perpetual warranty as follows. Hivemind will cover repair and shipping costs for damage from ordinary wear and tear. If the product has been mistreated or operated outside specification then the customer is liable to pay for the cost of the product and return shipping.

Other details of warranty are specified in the Hivemind Terms and Conditions at <http://hivemind.co.nz/agreement>.